

# ROUGH OPENINGS GUIDE

## MASONRY FRAME OPENINGS

SERIES 801 ATW				SERIES 500 SH
CODE	SINGLE	DOUBLE	TRIPLE	HEIGHTS
12	20"	39"	58 1/4"	26"
13	20"	39"	58 1/4"	38 3/8"
14	20"	39"	58 1/4"	50 5/8"
15	20"	39"	58 1/4"	63"
16	20"	39"	58 1/4"	74 1/4"
H32	27 1/2"	54"	80 1/2"	26"
H33	27 1/2"	54"	80 1/2"	38 3/8"
H34	27 1/2"	54"	80 1/2"	50 5/8"
H35	27 1/2"	54"	80 1/2"	63"
H36	27 1/2"	54"	80 1/2"	74 1/4"
22	38"	75"	112"	26"
23	38"	75"	112"	38 3/8"
24	38"	75"	112"	50 5/8"
25	38"	75"	112"	63"
26	38"	75"	112"	74 1/4"
32	54"	107 1/4"	160 3/8"	26"
33	54"	107 1/4"	160 3/8"	38 3/8"
34	54"	107 1/4"	160 3/8"	50 5/8"
35	54"	107 1/4"	160 3/8"	63"
36	54"	107 1/4"	160 3/8"	74 1/4"

MASONRY HEIGHTS: Measure From Top Lip Of Precast Sill To Bottom Of Beam.

